

Mulberry Fireside Chair


Assembly Instructions



Available in:



Beige



Chocolate

Product Specifications (RR05055)

Height	108.5cm
Depth	83cm
Width	70cm
Seat Height	52cm
Seat Depth	53cm
Seat Width	50cm
Max User Weight	19 stone

Product Code: RR05055

WARNING!

Please read before use:

- The fittings of our fireside chairs should be tightened every two to three months.
- The chair should not be assembled if any fittings are missing from the pack.
- Do not sit on arms or stool.
- Do not use power tools as they can damage threads.
- To clean the chair wipe down with a damp cloth using water only.
- Do not put any part of chair in direct sunlight.
- Do not place near heat.
- To move chair, lift, do not drag as this will damage chair.
- Maximum user weight of 19 stone.

Assembly Instructions:

- Place the front legs (2) into the holes on the underside of the chair. Using the bolt (6), washer (8) and the Allen Key provided (9) fasten the front legs in place as shown in image 1.
- Repeat for rear right and left legs (3) using the bolt (6), washers (8) and Allen key (9) provided as shown in image 2.
- Secure the footstool top (5) to the footstool base (4) by lining up the holes on the underside of both and secure in place using bolts (7), washers (8) and Allen key (9) provided as shown in image 3.
- Secure the footrest legs (2) to the base of the footstool in the same way as performed for the front legs of the chair, using bolts (6), washers (8) and Allen key (9) provided.

Note: It is possible when unpacking this product to experience a degree of wrinkling on covers. This will correct itself in the first weeks of use when placed in an aired room.

