



CARTON CONTENTS

Lamp x 1 | Pole Assembly x1 | Base x 1 | Power Supply x1

Contact CareCo immediately if any of the listed contents are missing.

ASSEMBLY



1. Remove all components from the outer packaging and place them onto a level surface.



2. Screw the pole assembly sections together.



3. Screw the pole assembly into the base.



4. Connect the pole assembly power cable to the lamp.



5. Screw the lamp into the pole assembly.



6. Insert the power supply cable into the base and plug into a wall socket.

OPERATING

SWITCHING ON/OFF

Touch the power button to turn [ON] the lamp.
Touch the power button again to turn [OFF] the lamp.

BRIGHTNESS SETTING

The lamp has 3 brightness settings:

- 6000K – Cool White
- 4500K – Daylight White
- 3000K – Warm White

Touch the power button to turn [ON] the lamp.

Switch [OFF] and [ON] again within 5 seconds to change the brightness setting.

SPECIFICATION TABLE

Power	LED 12W
Colour	Black / Pink
Switch type	Touch control
Dimmable	Yes
Max brightness	850 Lumen
External adapter	DC14V, 0.75A
Power cord length	180cm
Box Size	41.5 x 28.5 x 9.5cm
Package weight	4.3kgs
Carton size	43 x 30 x 30.5cm

MATERIAL LIST

Package: cardboard, LDPE, polyfoam

Lamp: ABS, PC, IRON, Aluminium, PVC, Silastic, Copper, Zinc, Sand, Cement

DIMMING

Whilst switched [ON], touch and hold the power button to gradually dim the light to the desired brightness.

Release the button to set the brightness.

AUTOMATIC SETTING SAVE

Switch [ON] the lamp after 5 seconds to return to the last setting.

